

Warning:

- 1-Ride-on car is designed for children 12-36 months old.
Ride's weight must not exceed 27kgs. as there is insufficient strength to support overweight.
- 2-Product is designed to seat 1 child as a time to avoid injuries.
- 3-Parental guidance and supervision are strongly advised to ensure safe riding.
- 4-Adult assembly and installation of all parts are required to ensure safety.
- 5-Batteries to be handled by adults.
- 6-take care of riding and avoid going near streets.crossroads,all traffic areas,swimming pools,and stairs.
- 7-Without regular check of the product.it will cause overturn or fall
- 8-Check to see occasionally that the nut and bolt on the steering wheel is tight and secure.
- 9-Dangers may present if the product is not correctly assembled.
- 10-Shoes must be worn in use.

Battery Handling:


- 1-Battery must be handled by adults only.
- 2-Always remove exhausted batteries.
- 3-Use AA size batteries only.
- 4-Alkaline batteries are recommended.
- 5-Always remove batteries when the unit is not going to be used for an extended period of time.
- 6-When replacing new batteries,always replace all batteries.
- 7-Do not mix old and new batteries.
- 8-Do not mix Alkaline,Standard(Carbon-Zinc),or Rechargeable(Nickel-Cadmium)batteries.
- 9-Do not dispose of batteries in fire,batteries may explode or leak.
- 10-Non-rechargeable batteries are not to be recharged
- 11-Rechargeable batteries are to be removed from the toy before being charged
- 12-Rechargeable batteries are only to be charged under adult supervision
- 13-Batteries are to be inserted with the correct polarity
- 14-The supply terminals are not to be shortcircuited

Item No:614/614W Activity Ride-On

Instructions Manual




Parts List:




INSTRUCTIONS

- 4 Assemble the safty bar into the backrest,then turn and fix in the steering wheel.
- 3 Insert the backrest into the hole in the back of the body,be certain the backrest is completely seated.
- 2 Insert the bolt into the hole of the steering wheel, then tight the nut with a screwdriver.




- 5 Insert the push bar into the hole of the backrest.
- 4 Assemble the safty bar into the backrest,then turn and fix in the steering wheel.


- 1 Insert the fork up through the hole in the front of the body and make sure the fork is positioned so that the supporter face the front.



- 6 Insert the footrest into the hole in opposite of the body,then push the footrest according to the arrow show in the picture.



BATTERY CHANGE



How to change the battery (only for 614W)

- Loosen the three screws with a screwdriver,then take the music box out.
- Loosen the screw of the battery cover,please keep all the screws in a safe place away from children's reach.
- Put 2 AA batteries in the battery house.
- Then tight all the screws with a screwdriver.