

Safe use of rules
Please by adults on the local assembly, please check whether the device and circuit assembly assembly process correctly.

Default of banned in the streets, highways, landslides and other dangerous places.

Children must be under the custody of adult use.

When used on the local, please do not usually change device.

Please use, shall not be frequently switch forward backward function.

Please check the battery, line, plugs, and other parts for damage and found damaged, please stop using in time,

Until the restored can be reused.

Should be in the right electrode in the battery,

Run out of battery should be removed from the toy.

The power terminals shall not be short.

Charging matters needing attention

1. using electric vehicles for the first time to charge first: Charging in car tail, charging charging must be made into do, do not let your children's access to power supply)
2. please recharge immediately when electric vehicle driving speed slowed significantly, continuous (charging 8 to 10 hours, not more than 10 small at the right time.
3. in the process of charging the charger or battery have fever phenomenon (under 60 °) are Normal.
4. the electric car must use local car equipped with dedicated charger and battery, so as not to damage the charger and battery and electric circuit.
5. the electric vehicle charging shall not do am operation.
6. please a mixture of old and new or different types of batteries
7. electric vehicle charging, please check whether the circuit connection is correct.
8. when the electric conductor time when not in use, must charge at least once every month.


Warning: electric car used in non private places, may lead to drowning, burns, falls and other hazards.

ELECTRIC CAR

Install and use the manual

Manual has an important information, read,


please keep for future reference.



- 1.Non rechargeable battery can not be charged
2. Power supply terminals shall not be short connectted
- 3.Rechargeable batteries can only be charged under adult guardianship
- 4.Diffenet types of batteries or do not mix old and new batteries
5. The batteryh should be put in the correct electrode
6. The exhausted battery should be removde from the toy
7. The charging battery should be taken out from the toy before charging
8. Contains small parts,not suitable for children under the age of 3 to use
9. Products should be properly assembled by the adults and then use
10. Please do not use in the streets roads landslider and other dangerous places must be used under adult guardianship
- Cannot be used in rainy days.
- Can not use water to clean.
- Assembly by an adult.”
- Protective equipment should be worn. Not to be used in traffic.”
- Warning.This toy is unsuitable for children under 3 years due to its maximum speed


TROUBLESHOOTING

PROBLEM	ANALYZE	SOLUTION
Car doesn't work	• Low power	Recharge the battery
	• Damage of thermal fuse	Change with new thermic fuse
Battery can't be recharged	• Lose of wheel nut	Use new nut
	• Loose of battery connector	Put on the connector
	• Exhaust & bad battery	Change with new battery
	• Damage on electrical parts	Go to repair shop
Short of run time	• Battery is old	Change new battery
	• Battery with lower power	Recharge the battery fully
	• Damage of charger	Change new charger
	• Charger doesn't plug the power	Plug charger with power
Low Speed	• Old battery	Use new battery
	• Low power	Recharge the battery fully
	• Over burden	Reduce burden under 25KG
	• Run on flat ground	Run on flat ground
Noise of gear box	• Damage of gear box	Go to repair shop
	• Damage on motor	Go to repair shop
	• Bad connect of motor wire	Reconnect the wire
	• Motor doesn't work well	Go to repair shop
No sound & light when running	• Loose of sound & light wire	Connect the wire
	• Damage of sound & light board	Go to repair shop
	• Damage of electrical parts	Go to repair shop
	• Remote control battery exhaust	Change battery
Unusual working condition under Remote control	• Remote control out of distance	Keep near distance between car and remote control
	• Damage of remote control	Change remote control
	• Damage of receiver board	Change receiver board
	• Disturb of magnetic filed	Far away from magnetic filed




Install the front wheel

On the gasket, the lining of the condom into the front axle, then the front wheel set into the front axle, and then set into the gasket and the locknut, with nut wrench should be fixed, cover the cap, about the same installation (as shown in figure 1)



Install the rear wheel

Will first car body over, remove manual damping spring and bushing inside, and then put a spring in car suspension hole, then set into the sleeve, and then use 10 mm rear axle through the sleeve, Then through the rear axle, gear box positioning box connected to car connect, then insert the wheel shaft, set into the big gasket, then its fixed with locknut, finally cover the wheel cover, (as shown in figure 2)



Install the steering wheel

Will line connectors and direction in the direction of dish stem the connectors are connected (note that connect the positive and negative). Then put the steering wheel in the direction of the pole, with the M5 inner hexangle set screw rod through the steering wheel and direction in turn, (as shown in figure 3)

20. Exhausted batteries are to be remove from the toy.

21. The supply terminals are not to be short-circuited.

22. Products should be properly assembled by the adults and then use.

23. Please do not use in the streets,roads,landslides and other dangerous places,must be used under adult guardianship.

DECLARATION:

1)Manual used in illustrations to explain the product of the operations and products, with the installation of structure in the existence of a small difference in kind, please standard the object.

part of the structure, and appearance, please forgive.

3)This package contains important information that must be to keep.

4)Cannot be used in rainy days.

5)Can not use water to clean.

6) Assembly by an adult.”

7) “Warning, Protective equipment should be worn. Not to be used in traffic.”

8)Toy operation requires a certain technology, should be more careful when used, lest collision and fall lead to injury and injury to others.

4)It's suitable for children for about 3-7 years old.
5)Cycle shall not leave the seat to prevent operation resulting in injury.
6)In the car was pulled, the device, such as a block, please immediately release switch to eliminate the obstacles and foot before you ride.

-8-


-1-

-4-

Install know that


Install windscreen

First remove the windscreen, then align the windscreen frame to the vehicle body, and press firmly to hear the kachasheng installation in place. (as shown in figure 7)




Functional instructions

1 first open the key to the total power supply, the lights lit up and accompanied by the start of the sound 2 move the steering wheel button, this time the music rings. Sound size adjustment will be up and down the first switch key press, can be achieved 3 the upper left corner of the music board is MP3 interface, the following is the memory card insertion port and next to the USB jack.4 point move "story /V+ " key, this time for the story mode.5 "music /V- " button, at this time for the song mode.6 point move "ancient poetry / play" key, this time for the ancient poetry mode.7 "early" button, at this time for early education mode.8 point "horn" key, this time for the speaker mode.9 "forward and backward" switch forward gear, step on the pedal switch car forward. Will "go back" after the switch back, step on the foot switch the car to run backwards. 11 the red circular switch is the swing start button, and the switch can realize the swing function. (as shown in Figure 8)




Installation mirror

First, differentiate the left and right Mirror, and then rewind. Insert the left and right of the door. (as shown in figure 4)




Charging instructions

Before installing seat first connect the positive, and then put seat in the specified location, card hook body card slot, then put the front seat fixed on both sides of the hole with the screw clockwise tightened when charging, open cover charge first, and then insert the charger to charge hole, when charging the vehicle without any function, (as shown in figure 5)



Remote control battery installation

First use the screwdriver to unscrew the screw on the battery cover, then take out the battery cover and remote control into two AAA1.5 V batteries, and battery cover cover and screw locking, (see figure 6)



SAFE RULES	
R/C Distance	15±5M
R/C Battery	AAA 1.5V * 2
Age	3-7 months - 95months
Speed	3-5 KM/H
Work Time	Recharge 8-12h,Use for 1-2h
Maximum load	30 KG
Charger	Input:AC220V~240V、50HZ~60HZ、Output:DC12V1A
Motor	12V15W
Battery	12V7AH 2*6V4.5AH

SPECIFICATION

The product to get c is the main ingredients of the important parts.

It's STANDARD NO.:EN71 EN62115 ASTM F963

Manual should be placed to take good care of.

methods of operation of this product damage or injury and your baby.

Use the product please first read instructions,it will tell you the correct methods of operation and installation instructions,To avoid not correct

UNIT MOUNT